

Panasonic KX-NT Series or KX-DT Series Phone



CT Lic. #125640
CT Lic. #122079



❶ Headset

❷ Soft Keys

❸ Call Control Buttons

❹ LCD Display

❺ Flexible
Keys

❻ Dial Pad

❼ Message/Ringer
Lamp

❽ Navigation

❾ Feature Control Buttons

❿ Headset Jack

TO PLACE A CALL

- Lift Handset or press speaker-phone button
- External call: Dial "9" or press an outside line button - Dial desired number
- Internal call: (Intercom Call): Dial extension number OR press pre-programmed extension (DSS) key

TO ANSWER A CALL

- When your phone rings and lamp flashes: Lift handset or press speakerphone button

TO TRANSFER A CALL

- With the caller on line press the transfer button
- Dial the extension number or press the "DSS" button
- Announce the call and hang up the handset

TO TRANSFER A CALL TO ANOTHERS VOICEMAIL BOX

- With the caller on line press the Voice mail transfer key
- Dial extension number OR press extension "DSS" key and hang up the handset

PUTTING A CALL ON HOLD

- With the caller on the line press the hold button
- The active outside line button flashes green on your phone
- If the call is not picked up (in a certain amount of time) the caller will ring back to your phone

TO RETRIEVE A CALL ON HOLD

- Press the line button that the call is being held on. Lamp will turn solid green - begin speaking

CONFERENCE CALLING

- Yourself and up to eight other callers (internal or external)
- With caller on line, press the conference button
- Dial second number (or extension #) - when connected announce call and press conference button again; the conference call will be completed
- Repeat same procedure for additional members

LINE TO LINE TRANSFER

- With caller on line, press the transfer button
- Select another line - dial the number
- When connected, announce the call and then press transfer button again and hang up